

ArmadLock modification for the installation to side sliding door on WV Caddy

The configuration of the side sliding door of WV Caddy doesn't allow to install ArmadLock to this door on the "standard" way (as for example to Ford Transit – where it's enough space to install the lock on such way)



Ford Transit Installation

- It's enough space between sliding and driver (or passenger) door to install ArmadLock

In WV Caddy there is now such space



WV Caddy sliding and passenger doors position

The only way to solve the problem is to install ArmadLock on non-standard way – on opposite to the handles side of sliding door



Such way was checked with WV dealer.

The conclusion – due to door specific design to be installed and work properly ArmadLock has to be modified. The only modification necessary is to increase the length of locking bolt to 5 mm:

